



The following template can be printed and traced onto the material you are using for a hub. The small wire holes around the edge should be 1/16" dia, while the center hole depends on your your method of mounting the wheel. The method described in this article calls for a 3/8" dia. center hole.

The distance from the center point to any corner should be about 2-3/4". If your printout is far from this dimension, you can use a ruler to draw lines from each corner to the center point, then mark new corner points at the correct distance and redraw the triangle.